





## How to Scan a Battery Change

### Step 1




Select "Change Battery" on menu and press [Enter], or press "1".

### Step 2




Scan the barcode on the truck

### Step 3




Find the **deadman hours** from the truck hourmeter. Type the number into the scanner.

### Step 4




Scan the barcode on the battery that is being removed from the truck.

### Step 5



Scan the barcode on the battery that is being put into the truck.

### Step 6



Press [Enter] or "1" to confirm and save.

### Step 7



Scanner shows that the information was sent to the control box.