



A Controller – Move jumper into position that matches charger DC voltage

0	-	Auto
1	-	12V
2	-	24V
3	-	36V
4	-	48V
5	-	72V
6	-	80V

24V DC Power

Yellow Jumper is moved to position 2 for 24v batteries

B Controller – Connect power and data cable

C Connect Both Data Cables to charger monitoring device

Plug into either socket

D Mount charger monitoring device near SB Connector or on charger

E Connect Flexi-Taps to Charger Cables

F Installed System

Pick this Battery

G System Check: to confirm good connection

1. Stop Charger then Disconnect each battery,
2. Reconnect Battery
3. Confirm amber LED illuminates

OK