



# OWNER'S MANUAL








EGO-GW-C1






### **EGO!GATEWAY™ OWNER'S MANUAL**


#### **TOOLS REQUIRED**




#### **EGO!GATEWAY INSTALLATION**




Mount the control box to the wall using four screws/anchors and a level. Make sure it is firmly attached to the wall.



Attach antenna to the eGO!gateway $^{\text{\tiny TM}}$ .



Place the antenna as high as possible to maximise signal.




Powering the device.

Table 1: Installation Locations

	Avoid Locations
Battery Room (*In-range of eGOs)	Exterior Location
	Humid Areas (e.g. Boiler Room)
Main Charging Area (*In-range of eGOs)	Enclosed Spaces
	Metal Clad Areas

#### START-UP LED SEQUENCE





 ${}^*\mbox{If the Red LED}$  illuminates, please contact your local supplier.



## FOR PRODUCT SPECIFICATIONS, USER GUIDES AND FURTHER INFORMATION PLEASE VISIT:

https://www.phlsci.com/product-lines/battery-performance-monitors

DOC0651@ 2025 Philadelphia Scientific UK Ltd. All Rights Reserved. Philadelphia Scientific and the PS logo are registered trademarks of Philadelphia Scientific LLC. eGO! and eGO!gateway are trademarks of Philadelphia Scientific UK Limited. EGO.E. R1-170625

