



## **INSTALLATION & OPERATION**






#### A STEALTH WATERING SYSTEM™ KIT includes:




18 Cell Stealth Watering System<sup>™</sup> Kit for 36 Volt Batteries


- Number of Stealth valves
- Input Assembly x1
- B End Plugs x2
- Quick Connect Coupling (x1)
- Coil of Tubing x1
- Cable Ties x2




#### **SECTION 1: INSTALLATION**




Remove the vent caps from each battery cell.




Place a Stealth valve into the vent hole of each battery cell and press it firmly into place.




Ensure there is clear access to both of the valve's tubing barbs.



Locate the Stealth valves with end plugs where the system will terminate.




Fully push the free end of the tubing onto the first valve's barb and push it firmly until it stops.




Measure the tubing to the middle of next valve in the sequence, ensuring a small amount of slack.


#### **SECTION 1: INSTALLATION (Cont'd)**




Cut the tubing squarely at this point using a tubing cutter, ensuring end of tubing is not crushed.




Push the cut end of the tube onto the second valve barb and press it firmly.




Make sure the tubing is cut squarely and fully inserted onto each barb, in case of leaking.



Apply the same cut to connect and secure all the valves and the remaining tubing.




Choose a suitable\* position for the Water Input Assembly and cut the tubing. (\*The position varies based on the different number of cells, please refer to the sample layouts shown on page 6.)




Connect the Water Input Assembly by firmly inserting the tubes in the same way as with the valves.


### **SECTION 1: INSTALLATION (Cont'd)**




Secure the Input Assembly to an intercell connector using a cable tie.



Slide the twist-lock ring onto the free end of the Water Input Assembly.




Insert the barb-fitting of male-quick-connect-fitting into the tubing.




Push twist-lock ring to connect quickly and twist to lock into the tubing.


#### **SAMPLE CELLS LAYOUT**



Sample 12-Cell Layout




Sample 18-Cell Layout




Sample 24-Cell Layout


#### **SECTION 2: OPERATION**




Working pressure is between 3-45psi (0.21-3.10 bar).




Connect the quick-connect fitting to a suitable water supply.




Filling will begin as soon as the connection is made (filling method dependent).



The filter traps impurities before they enter the Stealth valve and your batteries. If the filter is clogged or filling-time becomes longer, it is time to change the filter. (Part ID: FLT-104)




When all the valves' yellow fill level indicators pop up, the water is filled at the right level. **Note:** The spinner may not come to a complete stop, especially in larger systems. The battery is filled when the spinner slows enough to clearly see the inner blades/vanes.




Once the filling is completed, disconnect the quick-connect.


#### **SECTION 3: VALVE REMOVAL**



To remove a valve, insert an insulated screwdriver (or similar) under the lip of the valve.



Gently pry the valve out by levering around the lip.



Do not try to remove the valve by pulling on the tubing.



# FOR PRODUCT SPECIFICATIONS, USER GUIDES AND FURTHER INFORMATION PLEASE VISIT:

https://www.phlsci.com/product-lines/stealth-watering-system/

DOC0534 © 01/2023 Philadelphia Scientific UK Ltd. All Rights Reserved. Philadelphia Scientific and the PS logo are registered trademarks of Philadelphia Scientific. Stealth is a trademarks of Philadelphia Scientific LLC. E&O.E.



#### WWW.PHLSCI.COM