Instant Install™ Injector System

INJ-P18-812

RECOMMENDED LAYOUT FOR BATTERY TYPE

Approx. Tray Size 37.88" x 17.69"

18 Cell-15 Plate

Phone (215) 616-0390

Website www.phlsci.com

(215) 616-0500

Notes: 1. Remove any twists in the tubing prior to installation.

- 2. Tubing can run either over or under the cables depending on clearances.
- 3. Install tubing under cables where cable swing is possible.
- 4. Be sure all cables are tied down with wire ties to prevent system damage.

